

OPERATOR'S MANUAL

INCLUDING: SERVICE KITS, GENERAL DESCRIPTION & TROUBLESHOOTING
ALSO INCLUDE MANUALS: 6641X-X AIR MOTOR MANUAL, FORM 3637-2 GENERAL INFORMATION SHEET.

3" AIR MOTOR
50:1 RATIO
2 1/4" STROKE

BASIC PUMP
35 LB DRUM

72633-D
72633-1-D

RELEASED: 6-21-95
(REV. A) IPP/PSE



READ THIS MANUAL CAREFULLY BEFORE INSTALLING,
OPERATING OR SERVICING THIS EQUIPMENT.

SERVICE KITS

- Use only genuine ARO® replacement parts to assure compatible pressure rating and longest service life.
- 637066-B for repair of Air Motor section.
- Order individual parts separately for repair of Lower Pump End.

GENERAL DESCRIPTION


This model is designed for delivery of heavy viscosity fluids such as chassis lubrication fluids. Material dispensing accessories and supply lines and fittings must be capable of withstanding pressures developed by pump.

- The ARO 50:1 ratio basic pump assembly consists of a 3" air motor and lower pump end.

RATIO x REGULATED AIR PRESSURE TO AIR MOTOR = MAXIMUM FLUID PRESSURE.

- The 50:1 ratio is an expression of the relationship between the air motor area and the lower pump end area. When 150 p.s.i. (10 bar) air pressure is supplied to the air motor, the lower pump end will develop a maximum of 7,500 p.s.i. (517 bar) fluid pressure (at no flow) – as the fluid control is opened, the flow rate will increase as the air motor cycle rate increases to keep up with the demand.

PUMP DATA



OPERATING AND SAFETY PRECAUTIONS

- **HEED ALL WARNINGS.**
- **DO NOT EXCEED MAXIMUM WORKING PRESSURE OF 7,500 PSI (517 BAR) AT 150 PSI (10 BAR) AIR INLET PRESSURE.**

⚠ WARNING : HIGH PRESSURE DEVICE. Improper usage of this equipment could result in serious injury. The possibility of injection into the flesh is a potential hazard. Never allow any part of the human body to come in front of or in direct contact with the material outlet. An injection injury can be serious. If injection should occur, contact a qualified physician immediately for treatment.

- **COMPONENT RUPTURE.** This pump is capable of producing high material pressure as stated on pump model plate.
- Be sure material hoses and other components are able to withstand fluid pressures developed by this pump.

- Do not operate pump continuously at speeds in excess of 75 cycles per minute.

⚠ WARNING : PREVENT STATIC SPARKING. If static sparking occurs, fire or explosion could result. Pump, dispensing valve and containers must be grounded when handling inflammable fluids such as petroleum products, paints, lacquers, etc. and wherever discharge of static electricity is a hazard.

- Use grounded hoses (static wire) and be sure the object is grounded if it can produce a static charge.
- Use grounded hoses (static wire) and be sure the object is grounded if it can produce a static charge.
- Disconnect air line from pump air motor when system sits idle for long periods of time.

THE ARO CORPORATION • ONE ARO CENTER • BRYAN, OHIO 43506-0151

☎ (419) 636-4242 • FAX (419) 636-2115

©1995 THE ARO CORPORATION • PRINTED IN U.S.A.



Part of worldwide Ingersoll-Rand

AIR AND LUBE REQUIREMENTS

⚠ WARNING **HAZARDOUS PRESSURE.** Do not exceed maximum inlet air pressure of 150 psi (10 bar). Operating pump at higher pressure may cause pump damage and/or personal injury and/or property damage.

- Refer to general information sheet for additional safety precautions and important information.
- Excessive air pressure will shorten the life of the pump.
- For maximum operating efficiency, the following air supply specifications should be maintained to this pump.
 - AIR PRESSURE – Up to 150 P.S.I. (10 Bar)
 - AIR FILTRATION – 50 micron
 - LUBRICATED AIR SUPPLY
 - AIR INLET SIZE – 1/4" NPTF
- Filtered and oiled air will allow the pump to operate more efficiently and yield a longer life to operating parts and mechanisms.
- Lack of or an excessive amount of lubrication will affect the performance and life of this pump. Use the recommended lubricants.
- **DAILY: Fill air line lubricator with a good grade of S.A.E. NO. 90 W non-detergent gear oil, adjust to 1 to 2 drops per minute.**
- If pump is to be inoperative for more than a few hours at a time, disconnect air supply and relieve all pressure from the system.

It is recommended that an oiler be installed in the airline as close as possible to the pump. This increases the service life of the pump by reducing wear of the air motor's internal parts.

INSTALLATION

FLUSH PUMP

1. Connect fluid hose to pump outlet and be sure all fittings are tight.
 2. Turn air regulator knob counter-clockwise until it turns freely.
 3. Pump has been tested in oil and a small amount remains for protection against rusting. Immerse lower pump end in compatible solvent.
 4. Connect air hose coupler to connector on FRL.
 5. Turn air regulator knob clockwise until air motor starts operating.
 6. Flush pump with oil.
 7. Disconnect air supply from air motor.
- **CAUTION:** Solvent used for flushing may not be compatible with material being pumped. If this is the case, flush again with a compatible solvent.
 - If pump is to be inoperative for an unspecified period of time, disconnect air and relieve all pressure.
 - If pump does not function properly, disconnect air and relieve all pressure. Refer to Trouble Shooting.

OPERATING INSTRUCTIONS

1. Turn air regulator knob clockwise until air motor starts to cycle.
2. Allow pump to cycle slowly until it is primed and all air is purged from the fluid hose or dispensing valve.
3. Turn off dispensing valve and allow pump to stall—check all fittings for leakage.
4. Change air regulator setting until desired pressure and flow is obtained.
5. Inspect airline filter, open petcock to flush moisture or residue from bowl.
6. Pump is recommended to operate between 30 PSI and 150 PSI (not to exceed 75 cycles per minute.)

MAINTENANCE

The basic pump consists of two major components: 1. Air Motor, 2. Lower Pump. The air motor is removable and is to be serviced separately. Refer to air motor manual for service and parts.

- Periodically flush entire pump system with a solvent that is compatible with the material being pumped.
- Refer to disassembly procedures of air motor for correct breakdown.
- Disassembly should be done on a clean work bench with clean cloths to keep parts clean.
- If replacement parts are necessary, consult drawing containing parts for identification.
- Before assembling, lubricate parts where required. When assembling "O" rings or parts adjacent to "O" rings, care must be exercised to prevent damage to "O" rings and "O" ring groove surfaces.

PUMP DISASSEMBLY

NOTE: All threads are right hand.

CAUTION: DO NOT mar finish on (10) or (22) tube.

1. Clamp pump assembly in a vise on the air motor base assembly.
2. Place a strap wrench around (4) tube and loosen by turning counterclockwise. If the wrench slips on the (4) tube, wrap a piece of 400 sand paper around (4) tube and under strap wrench. (Note: Pipe wrench will damage the finish of the tube.)
3. After the (4) tube has been pulled down to expose the (2) rod, hold air motor piston rod and unscrew the (2) rod from the air motor piston rod.
4. Remove the air motor assembly from the vise.
5. Vise the lower pump and remove (22) primer tube from (10) tube.
6. Remove (21) cotter pin, (20) primer, (19) seat, (18) washer, (17) spacer, (16) body assembly (Disassemble body assembly if (14) "u" cup or (15) spacer needs to be replaced.) and (12) washer from assembly.
7. Remove (10) tube from (4) tube. Remove (5) gasket.
8. Pull rod assembly from (10) tube and disassemble (9) adapter from (7) plunger to remove (8) ball.

LOWER PUMP




FIGURE 2

PARTS LIST

ITEM	Description	Qty	Part No.
1	Gasket	1	70834
2	Rod (72643-D)	1	72645
	Rod (72654-D)	1	72641
	Rod (72654-1-D)	1	72641-1
3	Nut	2	Y11-106-C
4	Tube (72643-D)	1	72644
	Tube (72654-D)	1	72642
	Tube (72654-1-D)	1	72642-1
5	Gasket	1	70837
6	Ball Stop	1	83276
7	Plunger	1	71127
8	Ball	1	Y16-209
9	Adapter	1	70817
10	Suction Tube	1	71126
11	Primer Rod	1	72394
12	Washer	1	71524
13	Snap Ring	1	Y147-68
14	"U" Cup	1	Y186-4
15	Spacer	1	76705
16	Body	1	76704
17	Spacer	1	72392
18	Gasket	1	F21-65
19	Seat	1	6797
20	Primer	1	72387
21	Pin	1	Y15-21
22	Primer Tube	1	72389
23	Piston & Ball Check	1	71522
24	Piston & Tube	1	71523

PUMP ASSEMBLY

- Place (8) ball into (7) plunger and insert rod assembly into (10) tube. Add (5) gasket to (10) tube and screw (4) tube onto (10) tube.
- Place (12) spacer, (16) body assembly, (17) spacer, (18) washer, (19) seat and (20) primer into position. Secure by using (21) pin to keep primer in place.
- Screw (22) primer tube onto (10) suction tube.
- Place air motor assembly in vise by clamping onto the machined flats on the air motor base.
- Install (1) gasket in throat of air motor base.
- Thread rod assembly into piston rod of air motor.

TROUBLE SHOOTING

No Material. (Stalled Pump.)

- Obstructed Material Line. Disconnect air supply. Relieve all fluid pressure in pump. Remove Obstruction in system.

No Material (Pump Continually Cycles.)

- Empty material supply. Shut down system. Replenish material supply.

Material on one stroke only. (Fast Upstroke.)

- Item (7) cup packing is worn. Remove the cup packing. Replace cup packing.

Material on one stroke only. (Fast Downstroke.)

- Item (11) ball in (12) seat is not properly seating. Remove the seat. Clean and inspect ball and seat. If either is damaged. replace with new parts.

