


SECTION 31-9  
 PAGE NO. 5  
 DATE 6-1-88

# SALES AND ENGINEERING DATA

## "O" SERIES F/A NUTSETTERS MODELS 7453-D AND 7456-D LEVER THROTTLE

THIS PAGE SUPERSEDES:  
 SECTION 31-9  
 PAGE NO. 5  
 DATE 11-13-89



- ADAPTER 32377
- VALVE STEM 36602
- "O" RING Y325-7
- VALVE SPRING 31131
- NUT 36609
- REGULATOR 35642
- SEAL 35675
- HOUSING 36605
- HEAD ASS'Y 36604

- 32863 BAIL
- 40191 EXHAUST MUFFLER
- 36992 RIVET
- 36603 LEVER

\* INCLUDED WITH 30780 CYLINDER

- BEARING Y65-7
- END PLATE 30750
- \* PIN Y178-27
- CYLINDER 30780
- \* PIN Y178-23
- BLADE "C-2"
- END PLATE 31158
- BEARING Y65-15
- ROTOR "C-1"
- MOTOR ASS'Y "C"

- 32310 SPACER
- 32305 SPACER
- 36606 MOTOR HOUSING
- "A" AUXILIARY GEARING

SEE REVERSE SIDE OF THIS SHEET FOR GEARING PARTS LIST.

- NOT SHOWN
- Y106-7 ALLEN WRENCH

- "B" DRIVE GEARING

MODEL	R.P.M.	GEARING		MOTOR
		"A" AUXILIARY	"B" DRIVE	
7453-D	850	33853	33890	33807
7456-D	450		33891	33843

"C"	"C-1"	"C-2"	
MOTOR	ROTOR	BLADES	QT'Y
33807	30745	30741	(4)
33843	31633	31363	(5)

FITTING 35323 INCLUDED WITH HOUSING 36606

NOTE: ALL PARTS LISTED BELOW HEAVY BLACK LINES ARE INCLUDED IN 33534-5 FLAT ANGLE NUTSETTER ASS'Y

- \*\*PIN Y148-14
- \*\*SHAFT 33502
- \*\*FITTING 33517
- \*\*SPACER (3) 38600
- \*\*FITTING 35967
- \*\*SHAFT (3) 33499




- Y99-52 CAP SCREW
- 33498 LOCK NUT
- 31824 BEARING (2) †
- 33486 DRIVE SHAFT
- 39564 BEVEL GEAR
- 33493 SCREW
- 33535 HOUSING
- 40461 BEVEL GEAR (INCLUDES NEEDLE BEARING)
- 33518 GEAR (3) (INCLUDES NEEDLE BEARING)
- 33533 COVER PLATE
- 33532-5 ADAPTER
- 32349 SCREW (4)

† INSTALL BEARINGS 31824 WITH LETTERED FACES TOWARD EACH OTHER

\*\*PARTS ARE PRESS FIT TO AND INCLUDED WITH HOUSING 33535.

INSTRUCTION SHEET  
 FORM NO. 3473





## OPERATING PRECAUTIONS

**WARNING:** Repeated prolonged operator exposure to vibrations which may be generated in the use of certain hand-held tools may produce Raynaud's phenomenon, commonly referred to as Whitefinger disease. The phenomenon produces numbness and burning sensations in the hand and may cause circulation and nerve damage as well as tissue necrosis. Repetitive users of hand-held tools who experience vibrations should closely monitor duration of use and their physical condition.

## AIR AND LUBE REQUIREMENTS

AIR PRESSURE OF 90 p.s.i.g. (6 bar) at the air inlet of the tool is required for maximum motor efficiency. If necessary, an air regulator should be installed to maintain this pressure when tool is in operation.

FILTERED AND OILED AIR will allow the tool to operate more efficiently and yield a longer life to operating parts and mechanisms. A line filter capable of filtering particles larger than 50 microns should be used with a line oiler.

FILTER-REGULATOR-LUBRICATOR (F-R-L) assembly model 128231-800 is recommended for use with this air tool. The capacity of this F-R-L is adequate to provide clean (40 micron) oiled and regulated air for

the tool.

FLUSH TOOL with a solution of three parts cleaning solvent and one part light oil after each 40 hours of operation. After flushing, apply a small amount of spindle oil in air inlet and run free for one minute to insure proper lubrication.

RECOMMENDED HOSE SIZE – 3/8" (9 mm) nominal inside diameter.

RECOMMENDED LUBRICANTS: Spindle Oil 29665, 1 qt. (.9 liter) container for oiler and air inlet; Grease 33153, 5 lb. (2.3 kg) can for gears and bearings, "O" Ring Lubricant 36460, 4 oz. (113 g) tube for lubrication and installation of "O" rings.

## MAINTENANCE

DISCONNECT AIR SUPPLY from tool or shut off air supply line to tool and exhaust (drain) air line to tool of compressed air BEFORE performing service or maintenance to tool.

AIR TOOLS are made of precision parts and should be handled with reasonable care when servicing. Excessive pressure exerted by a holding device may cause distortion of a part. Apply pressure evenly when disassembling (or assembling) parts which have a press fit. When removing or installing bearings, apply pressure to the bearing race that will be the press fit to the mating part; if this is not practiced, Brinelling of the bearing races may occur making replacement necessary. It is important that the correct tools and fixtures are used when servicing this air tool.

DISASSEMBLY should be done on a clean work bench with a clean cloth spread to prevent the loss of small parts. After disassembly is completed, all parts should be thoroughly washed in a clean solvent, blown dry with air and inspected for wear levels, abuse and contami-

nation.

Double sealed or shielded bearings should never be placed in solvent unless a good method of relubricating the bearing is available. Open bearings may be washed but should not be allowed to spin while being blown dry. When REPLACEMENT PARTS are necessary, consult drawing containing the part for identification.

BEFORE REASSEMBLING, lubricate parts where required. Use 33153 grease, or equivalent, in bearings. Use 36460 lubricant for "O" ring assembly. When assembling "O" rings, care must be exercised to prevent damage to the rubber sealing surfaces. A small amount of grease will usually hold steel balls and other small parts in place while assembling.

WHEN ORDERING PARTS, be sure to list PART NUMBER, PART NAME, MODEL NUMBER AND SERIAL NUMBER OF TOOL. USE ONLY GENUINE ARO® REPLACEMENT PARTS.

## DISASSEMBLY AND REASSEMBLY OF TOOLS

### DISASSEMBLY

FLAT-ANGLE ATTACHMENT – To remove from tool; remove cap screw (Y99-52) and pull attachment off gearing. To remove shaft (33486) and/or components, remove lock nut (33498). For access to gears and components, remove four (4) screws (32349) and cover plate (33533).

GEARING – Remove flat-angle attachment. Remove drive gearing assembly from auxiliary gearing and remove auxiliary gearing from motor housing. Further disassembly should not be done unless damage is evident. Remove spindle and components from gear housing. Remove bearings, shafts and gears from spindle. Remove lock spring, pin, driver, and key from spindle.

MOTOR – The motor assembly can be removed after the removal of the gearing or head assembly. Grasp motor cylinder in one hand and tap splined end of rotor with a non-metallic hammer; motor will come apart.

THROTTLE VALVE – The throttle components can be removed without removing the head section from the tool. Remove nut (36609), seal, regulator, spring, and valve stem.

### ASSEMBLY

FLAT-ANGLE ATTACHMENT – Lubricate gears and bearings liberally with ARO 33153 grease. Assemble gears to shafts and assemble cover plate (33533). Secure with four (4) screws (32349). Assemble gear

(39564) to shaft (33486) and secure with screw (33493). Lubricate bearings (31824) with ARO 33153 grease and assemble to shaft (33486). NOTE: Assemble bearings with identification markings towards each other. Lubricate Gear (39564) liberally with ARO 33153 grease and assemble components to housing. Secure with lock nut (33498).

GEARING – Lubricate shafts and needle bearings with ARO grease 33153. Be sure shafts (33686) contain fifteen (15) needle bearings per shaft. Assemble gears to spindle and secure with shafts. Lubricate bearings with ARO 33153 grease and assemble spacers and bearings to spindle. Assemble key, driver, pin, and lock spring to spindle. Lubricate gears liberally with ARO 33153 grease and assemble to gear housing (adapter). Assemble gearing to tool.

MOTOR – Assemble bearings to end plates and assemble end plate (30750) to rotor. Coat i.d. of cylinder with spindle oil and assemble over rotor. Coat rotor blades with spindle oil and assemble to blade slots of rotor. Assemble end plate (33158), with bearing, to rotor and cylinder. Be sure rotor turns without binding. If rotor binds, tap splined end lightly with a soft face hammer to loosen.

With motor housing removed from head, assemble motor to head aligning roll pin of motor with .106 dia. blind hole in head. Slip motor housing over motor and thread to head. Assemble spacers (32310), (32305), and gearing to tool.

THROTTLE VALVE – Lubricate "O" ring (Y325-7) and assemble to valve stem. Assemble valve, spring, regulator, seal, and nut to housing.