


SALES AND ENGINEERING DATA

"O" SERIES F/A DRILLS SPINDLE MOUNTED-PLAIN BEARING LEVER TYPE



EXHAUST MUFFLER 40191
RIVET 36992
LEVER 36603

32863 BAIL
32377 ADAPTER
36602 VALVE STEM
Y325-7 "O"RING
31131 SPRING
36609 NUT
35642 REGULATOR
35675 SEAL
36605 HEAD
36604 LEVER HEAD ASS'Y
Y65-7 BEARING
30750 END PLATE
Y178-27 ROLL PIN *
30780 CYLINDER
Y178-23 ROLL PIN *
"C-2" BLADE ()
31158 END PLATE
Y65-15 BEARING
"C-1" ROTOR
"C" MOTOR ASS'Y
32310 SPACER
36606 HOUSING
32305 SPACER
32325 BEARING
37676 SPACER
30899 GEAR (2)
33686 SHAFT (2) * *
30901 SPLINE GEAR
32314 SPACER
32325 BEARING
Y147-7 RET. RING
32326 HOUSING
37667 SPINDLE
"A" (3.4-1) GEARING ASS'Y
"B" DRIVE GEARING

"C"	"C-1"	"C-2"	
MOTOR ASS'Y	ROTOR	BLADES	QTY
33807	30745	30741	(4)
33843	31633	31383	(5)

MODEL	R.P.M.	GEARING		MOTOR ASS'Y
		"A" AUXILIARY	"B" DRIVE	
7438-D	1,450	33853	33890	33807
7439-D	2,500	-	33891	33843
7441-D	3,300	-	33889	33807

NOTE: ALL PARTS LISTED BELOW
HEAVY LINES ARE INCLUDED
IN 33342 FLAT ANGLE
DRILL ATTACHMENT ASS'Y

* INCLUDED WITH CYLINDER

† INSTALL BEARINGS 31824 WITH
LETTERED FACES TOWARD EACH OTHER



** INCLUDES 15 NEEDLE
BEARINGS PER SHAFT

NOT SHOWN
SCREW (4) 32349


Y99-52 CAP SCREW
33498 LOCK NUT
31824 BEARING (2) †
33486 DRIVE SHAFT
39564 BEVEL GEAR
33493 SCREW
40461 GEAR
33343 HOUSING
33518 GEAR (2)
33519 GEAR
Y65-10 BEARING
33500-3 GEAR ADAPTER
33340 COVER PLATE

INSTRUCTION SHEET-FORM NO. 3224





** INCLUDES 15 NEEDLE BEARINGS PER SHAFT



OPERATING PRECAUTIONS

WARNING: Repeated prolonged operator exposure to vibrations which may be generated in the use of certain hand-held tools may produce Raynaud's phenomenon, commonly referred to as Whitfingert disease. The phenomenon produces numbness and burning sensations in the hand and may cause circulation and nerve damage as well as tissue necrosis. Repetitive users of hand-held tools who experience vibrations should closely monitor duration of use and their physical condition.

AIR AND LUBE REQUIREMENTS

AIR PRESSURE OF 90 p.s.i.g. (6 bar) at the air inlet of the tool is required for maximum motor efficiency. If necessary, an air regulator should be installed to maintain this pressure when tool is in operation.

FILTERED AND OILED AIR will allow the tool to operate more efficiently and yield a longer life to operating parts and mechanisms. A line filter capable of filtering particles larger than 50 microns should be used with a line oiler.

FILTER-REGULATOR-LUBRICATOR (F-R-L) assembly model 128241-800 is recommended for use with this air tool. The capacity of this F-R-L is adequate to provide clean (40 micron) oiled and regulated air for

the tool.

FLUSH TOOL with a solution of three parts cleaning solvent and one part light oil after each 40 hours of operation. After flushing, apply a small amount of spindle oil in air inlet and run free for one minute to insure proper lubrication.

RECOMMENDED HOSE SIZE — 5/16" (8 mm) nominal inside diameter.

RECOMMENDED LUBRICANTS: Spindle Oil 29665, 1 qt. (.9 liter) container for oiler and air inlet; Grease 33153, 5 lb. (2.3 kg) can for gears and bearings, "O" Ring Lubricant 36460, 4 oz. (113 g) tube for lubrication and installation of "O" rings.

MAINTENANCE

DISCONNECT AIR SUPPLY from tool or shut off air supply line to tool and exhaust (drain) air line to tool of compressed air BEFORE performing service or maintenance to tool.

AIR TOOLS are made of precision parts and should be handled with reasonable care when servicing. Excessive pressure exerted by a holding device may cause distortion of a part. Apply pressure evenly when disassembling (or assembling) parts which have a press fit. When removing or installing bearings, apply pressure to the bearing race that will be the press fit to the mating part; if this is not practiced, Brinelling of the bearing races may occur making replacement necessary. It is important that the correct tools and fixtures are used when servicing this air tool.

DISASSEMBLY should be done on a clean work bench with a clean cloth spread to prevent the loss of small parts. After disassembly is completed, all parts should be thoroughly washed in a clean solvent, blown dry with air and inspected for wear levels, abuse and contami-

nation.

Double sealed or shielded bearings should never be placed in solvent unless a good method of relubricating the bearing is available. Open bearings may be washed but should not be allowed to spin while being blown dry. When REPLACEMENT PARTS are necessary, consult drawing containing the part for identification.

BEFORE REASSEMBLING, lubricate parts where required. Use 33153 grease, or equivalent, in bearings. Use 36460 lubricant for "O" ring assembly. When assembling "O" rings, care must be exercised to prevent damage to the rubber sealing surfaces. A small amount of grease will usually hold steel balls and other small parts in place while assembling.

WHEN ORDERING PARTS, be sure to list PART NUMBER, PART NAME, MODEL NUMBER AND SERIAL NUMBER OF TOOL. USE ONLY GENUINE ARO® REPLACEMENT PARTS.

DISASSEMBLY AND REASSEMBLY OF TOOLS

DISASSEMBLY

Remove exhaust muffler ass'y (40191) from exhaust outlet. Remove adapter (32377) from air inlet. Unscrew bolt (Y99-52) and remove flat angle attachment.

VALVE: Place tool in holding device, securing on flats of head. Unscrew nut (36609) and valve parts may easily be removed.

GEARING: Holding ring gear (32326) with a wrench, unscrew ring gear (33485) and remove drive gearing. Holding motor housing (36606) with strap wrench (640-081), unscrew ring gear (32326) and remove auxiliary gearing. On the drive gearing assembly, remove spring (31551), pin (31552), driver (33496) and key (31409). Grasp ring gear in one hand, tap end of spindle with plastic hammer until gearing is released from ring gear. Remove rear bearing; press planet gear shafts out of spindle releasing planet gears and bearings. Remove front bearing and spacer.

MOTOR: Using strap wrench, remove motor and motor housing assembly (36606). Tap splined end of rotor with plastic hammer to remove motor from housing. Grasp motor cylinder (30780) in one hand and tap splined end of rotor until motor comes apart.

FLAT ANGLE: Remove lock nut (33498), bearings (31824), shafts (33486) and bevel gear (39564) from housing. Unscrew sems fastener (33493) to release gear (39564) from shaft. Remove (4) screws in cover plate which will release bearings and drill bit adapter.

REASSEMBLY

VALVE: Assemble valve stem (36602), spring (31131), regulator

(35642), and seal (35675) into valve opening in head and secure with nut (36609).

MOTOR: Assemble rear end plate (30750) and bearing to cylinder and pin assembly (30780). Assemble blades to rotor and assemble into cylinder and end plate. Assemble front end plate (31158) and bearing to cylinder and rotor. Be sure motor spins freely, then assemble into motor housing assembly (36606) and assemble to head.

GEARING: Assemble spacer and bearing to drive end of spindle. Assemble planet gears and bearings into spindle and secure with planet gear shafts. Align planet gear shafts to spacer with a small screwdriver. Assemble bearing to rear end of spindle. This method applies to both gearing assemblies. If gearing assembly has loose needle-type bearings, apply a small amount of grease to bearings to hold them in place while assembling. Assemble key (31409), driver (33496) and pin (31552) to spindle of drive gearing and secure with spring (31551). Assemble spacer (32305) and gearing to tool.

FLAT ANGLE: Place bearings, gear (40461) and drill bit adapter into housing. Place cover plate in place and secure with (4) screws. Assemble gear (39564) to shaft (33486) and secure with sems fastener (33493). Assemble shaft (33486) and bearings (31824) into housing and secure with lock nut (33498). NOTE: Assemble bearings with identification markings towards each other. Assemble flat angle attachment to tool and secure with screw (Y99-52).

Assemble exhaust muffler ass'y (40191) to exhaust outlet and adapter (32377) to air inlet of tool.