



Tool Products

# OPERATOR'S MANUAL

INCLUDING: OPERATION, INSTALLATION & MAINTENANCE

SECTION M22

MANUAL 80


Released: 9-3-90

Revised: 11-10-95

Form: 3698-2

## 20 SERIES 45° DRILLS

Models: DA023B-( )-( ) and DA025B-( )-( ).



### ⚠ WARNING

**READ THIS MANUAL CAREFULLY BEFORE INSTALLING, OPERATING OR SERVICING THIS EQUIPMENT.**

#### FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

Pneumatic tools should always be installed and used in accordance with A.N.S.I. B186.1 "Safety Code For Portable Air Tools."

#### ⚠ WARNING

- Operate this tool at 90 p.s.i.g. (6.2 bar) maximum air pressure at the air inlet of the tool.
- Disconnect air supply from tool before removing/installing bit, socket or device attached to tool or performing maintenance procedures.
- Keep hands, clothing and long hair away from rotating end of tool.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Never exceed rated r.p.m. of tool.
- Wear suitable eye and hearing protection while operating tool.
- Tool shaft can continue to rotate briefly after throttle is released.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.
- Use only accessories recommended by ARO.

#### ⚠ WARNING

Repeated prolonged operator exposure to vibrations which may be generated in the use of certain hand-held tools may produce Raynaud's phenomenon, commonly referred to as Whitefinger disease. The phenomenon produces numbness and burning sensations in the hand and may cause circulation and nerve damage as well as tissue necrosis. Repetitive users of hand-held tools who experience vibrations should closely monitor duration of use and their physical condition.

#### NOTICE

- The use of other than genuine ARO replacement parts may result in safety hazards, decreased tool performance and increased maintenance and may invalidate all warranties.
- ARO is not responsible for customer modification of tools for applications on which ARO was not consulted.
- Tool maintenance and repair should be performed by authorized, trained, competent personnel. Consult your nearest ARO authorized servicer.
- It is the responsibility of the employer to place the information in this manual into the hands of the operator.

For parts and service information, contact your local ARO distributor, or the Customer Service Dept. of the Ingersoll-Rand Distribution Center, White House, TN at PH: (615) 672-0321, FAX: (615) 672-0801.

ARO Tool Products

Ingersoll-Rand Company

1725 U.S. No. 1 North • P.O. Box 8000 • Southern Pines, NC 28388-8000


©1995 THE ARO CORPORATION • PRINTED IN U.S.A.



Part of worldwide Ingersoll-Rand

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

**⚠ WARNING**




**Wear eye protection when operating or performing maintenance on this tool.**

**⚠ WARNING**



**Wear hearing protection when operating this tool.**

**⚠ WARNING**



**Turn off air supply and disconnect air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.**

**⚠ WARNING**



**Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.**

**⚠ WARNING**



**Do not carry the tool by the hose.**

**⚠ WARNING**




**Do not use damaged, frayed or deteriorated air hoses and fittings.**

**⚠ WARNING**



**Do not overreach when operating this tool. Keep body stance balanced and firm.**

**⚠ WARNING**



**Operate at 90 p.s.i.g. (6.2 bar/620 kPa) maximum air pressure.**

**NOTICE**

**⚠ WARNING**

 Read the manual before operating this tool.  
Operate at 90 psig/6.2 bar max.

**PN 48176-1 LABEL (NON-EU MODELS)**



**PN 49883 LABEL (-EU MODELS)**

**This label must appear on the tool at all times. If it is lost or damaged, a replacement label is available at no cost.**

**WARNING = Hazards or unsafe practices which could result in severe personal injury, death or substantial property damage.**

**CAUTION = Hazards or unsafe practices which could result in minor personal injury or product or property damage.**

**NOTICE = Important installation, operation or maintenance information.**

## ROUTINE LUBRICATION REQUIREMENTS

Lack of or an excessive amount of lubrication will affect the performance and life of this tool. Use only recommended lubricants at below time intervals:

**EVERY 8 HOURS OF TOOL OPERATION** – Fill lubricator reservoir of recommended F.R.L. with spindle oil (29665). If an in line or air line lubricator is not used, apply several drops of spindle oil (29665) in air inlet.

**EVERY 160 HOURS OF TOOL OPERATION** – Lubricate gearing. Pack bearings, coat shafts and lubricate gears with NLGI #1 “EP” grease (33153). Gearing should contain approximately 1/32 oz. (.9 g) of grease for single reduction and 3/64 oz. (1.3 g) of grease for double reduction. Angle housing section should contain approximately 1/8 oz. (3.5 g) of grease.

## AIR SUPPLY REQUIREMENTS


For maximum operating efficiency, the following air supply specifications should be maintained to this air tool:

- AIR PRESSURE – 90 p.s.i.g. (6.2 bar)
- AIR FILTRATION – 50 micron
- LUBRICATED AIR SUPPLY
- HOSE SIZE – 5/16” (8 mm) I.D.

An ARO® model C28231–810 air line FILTER/REGULATOR/LUBRICATOR (F.R.L.) is recommended to maintain the above air supply specifications.

## RECOMMENDED LUBRICANTS

After disassembly is complete, all parts, except sealed or shielded bearings, should be washed with solvent. To relubricate parts, or for routine lubrication, use the following recommended lubricants:



Where Used	ARO Part #	Description
Air Motor	29665	1 qt. Spindle Oil
“O” Rings & Lip Seals	36460	4 oz. Stringy Lubricant
Gears and Bearings	33153	5 lb. “EP” – NLGI #1 Grease

## INSPECTION, MAINTENANCE AND INSTALLATION

Disconnect air supply from the tool or shut off air supply and exhaust (drain) line of compressed air before performing maintenance or service to the tool.

It is important that the tools be serviced and inspected at regular intervals for maintaining safe, trouble-free operation of the tool.

Be sure the tool is receiving adequate lubrication, as failure to lubricate can create hazardous operating conditions resulting from excessive wear.

Be sure that the air supply lines and connectors are of proper size to provide a sufficient quantity of air to the tool.


Tool maintenance and repair shall be performed by authorized, trained, competent personnel. Tools, hose and fittings shall be replaced if unsuitable for safe operation and responsibility should be assigned to be sure that all tools requiring guards or other safety devices shall be kept in legible condition. Maintenance and repair records should be maintained on all tools. Frequency of repair and the nature of the repairs can reveal unsafe application. Scheduled maintenance by competent authorized personnel should detect any mistreatment or abuse of the tool and worn parts. Corrective action should be taken before returning the tool for use.




Disassembly should be done on a clean work bench with a clean cloth spread to prevent the loss of small parts. After disassembly is completed, all parts should be thoroughly washed in a clean solvent, blown dry with air and inspected for wear levels, abuse and contamination. Double sealed or shielded bearings should never be placed in solvent unless a good method of re-lubricating the bearing is available. Open bearings may be washed but should not be allowed to spin while being blown dry.



Upon reassembling, lubricate parts where required. Use 33153 grease, or equivalent, in bearings. Use 36460 lubricant for “O” ring assembly. When assembling “O” rings or parts adjacent “O” rings, care must be exercised to prevent damage to the rubber sealing surfaces. A small amount of grease will usually hold steel balls and other small parts in place while assembling.

When replacement parts are necessary, consult drawing containing the part for identification.

Always use clean, dry air. Dust, corrosive fumes and/or excessive moisture can damage the motor of an air tool. An air line filter can greatly increase the life of an air tool. The filter removes rust, scale, moisture and other debris from the air lines. Low air pressure (less than 90 p.s.i.g.) reduces the speed of the air tool. High air pressure (more than 90 p.s.i.g.) raises performance beyond the rated capacity of the tool and could cause injury. Shown below is a typical piping arrangement.







MODEL NUMBER	R.P.M.	HOUSING ASS'Y (ITEM 9)	GEARING REDUCTION	ANGLE ASSEMBLY	DRIVE DESCRIPTION
DA023B-5-C	500	46722	44.49:1	48834-2	3/16" COLLET
DA023B-5-D	500	46722	44.49:1	48834-3	#10 - 32 FEMALE THREAD
DA023B-5-E	500	46722	44.49:1	48834-4	5/16 - 24 FEMALE THREAD
DA023B-5-T	500	46722	44.49:1	48834-1	1/4 - 28 FEMALE THREAD
DA023B-11-C	1100	46722	22.87:1	48834-2	3/16" COLLET
DA023B-11-D	1100	46722	22.87:1	48834-3	#10 - 32 FEMALE THREAD
DA023B-11-E	1100	46722	22.87:1	48834-4	5/16 - 24 FEMALE THREAD
DA023B-11-T	1100	46722	22.87:1	48834-1	1/4 - 28 FEMALE THREAD
DA023B-21-C	2100	46722	11.76:1	48834-2	3/16" COLLET
DA023B-21-D	2100	46722	11.76:1	48834-3	#10 - 32 FEMALE THREAD
DA023B-21-E	2100	46722	11.76:1	48834-4	5/16 - 24 FEMALE THREAD
DA023B-21-T	2100	46722	11.76:1	48834-1	1/4 - 28 FEMALE THREAD
DA023B-37-C	3700	46722	6.67:1	48834-2	3/16" COLLET
DA023B-37-D	3700	46722	6.67:1	48834-3	#10 - 32 FEMALE THREAD
DA023B-37-E	3700	46722	6.67:1	48834-4	5/16 - 24 FEMALE THREAD
DA023B-37-T	3700	46722	6.67:1	48834-1	1/4 - 28 FEMALE THREAD
DA023B-73-C	7300	46722	3.43:1	48834-2	3/16" COLLET
DA023B-73-D	7300	46722	3.43:1	48834-3	#10 - 32 FEMALE THREAD
DA023B-73-E	7300	46722	3.43:1	48834-4	5/16 - 24 FEMALE THREAD
DA023B-73-T	7300	46722	3.43:1	48834-1	1/4 - 28 FEMALE THREAD
DA025B-5-C	500	48330-1	44.49:1	48842-1	9/32 - 40 FEMALE THREAD
DA025B-11-C	1100	48330-1	22.87:1	48842-1	9/32 - 40 FEMALE THREAD
DA025B-21-C	2100	48330-1	11.76:1	48842-1	9/32 - 40 FEMALE THREAD



CANCELLED MODELS

MODELS WITH -EU SUFFIX ARE "EC" COMPLIANT MODELS.

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

1	Screen	33911	33	Washer	47694
2	Inlet Adapter	46377	34	Snap Ring	Y142-2
3	Spacer	47205	35	Planet Gear (3 or 6 req'd) 6.67:1 ratio (21 teeth)	46875
4	Washer	46371	36	Spindle 6.67:1 ratio	47741
5	Exhaust Cap	46366-1	37	Carrier Assembly 3.43:1 ratio	46493
6	Muffler Pad	48199-1	38	Sun Gear 3.43:1 ratio (21 teeth)	46560
7	Spring	41654	39	Ring Gear (double reduction)	46323
8	Valve Rod Assembly	46354	40	Carrier Assembly 6.67:1 ratio	46336
9	Housing Assembly	See table	41	Carrier Assembly 6.67:1 ratio	46720
10	Spring	46374	42	Coupling	48184-1
11	Throttle Pin	46296-1	43	"O" Ring	Y325-19
12	Lever	46326	44	Adapter	48186-1
13	Roll Pin	Y178-28	45	Lock Nut	48185-1
14	Restrictor	48322-1	46	Ball Bearing	Y65-8
15	"O" Ring	Y325-10	47	Angle Body	48196-1
16	Retaining Ring	Y147-3	48	Needle Bearing	46222
17	Ball Bearing	41643	49	Pinion	48836-1
18	Rear End Plate	46245	50	Housing	48833-1
19	Blade (5 req'd)	46301	51	Grease Fitting	35967
20	Rotor	46338-2	52	Gear (1/4 - 28 female thread)	48837-1
21	Cylinder	48200-1	53	Roller Bearing	44424
22	Front End Plate	47718	54	Ball (11 req'd)	Y16-203
23	Ball Bearing	Y65-10	55	Sleeve	48840-1
	MOTOR ASSEMBLY (includes items 17 thru 23)	48225-1	56	Gear	48838-1
24	"O" Ring	Y325-116	57	Collet Insert	43497-169
25	Spacer	46305	58	Gear (#10 - 32 female thread)	48841-1
26	Locating Pin	47719-2	59	Gear (5/16 - 24 female thread)	48839-1
27	Sun Gear 3.43:1 ratio (21 teeth)	46561	60	Gear (9/32 - 40 female thread)	48843-1
28	Planet Gear (3 or 6 req'd) 3.43:1 ratio (15 teeth)	46904	61	Angle Assembly	See table
29	Spindle 3.43:1 ratio	47742	62	Angle Assembly (see table)	48842-1
30	Ring Gear (single reduction)	46322			
31	Spacer	46496		SERVICE KIT: includes items 1, 6, 7, 10, 13, 15, 16, 19, 24, 33, 34, 48 and 54	48891
32	Ball Bearing	Y65-13			

- Never apply excessive pressure by a holding device which may cause distortion of a part.
- Apply pressure evenly to parts which have a press fit.
- Apply even pressure to the bearing race that will be press fitted to the mating part.
- Use correct tools and fixtures when servicing this tool.
- Don't damage "O" rings when servicing this tool.
- Use only genuine ARO replacement parts for this tool. When ordering, specify part number, description, tool model number and serial number.

## ANGLE HOUSING DISASSEMBLY

- Using wrenches on flats of ring gear and lock nut (45), unthread and remove angle housing section from tool – LEFT HAND THREADS.
- To disassemble angle housing section, grasp housing (50) lightly in a vise. Using a wrench on flats of body (47), unthread body from housing – LEFT HAND THREADS.
- Do not remove pinion (49) from housing unless damage is evident. To remove pinion, grasp pinion in a vise and tap housing with a soft face hammer.
- Unthread and remove adapter (44) – LEFT HAND THREADS – releasing bearing (46).
- To disassemble drive section, unthread sleeve (55) – LEFT HAND THREADS – and pull drive assembly from housing (50). Do not disassemble further unless damage is evident. NOTE: Drive assembly contains 11 small balls which will fall out if drive assembly is disassembled.

## ANGLE HOUSING ASSEMBLY

- Lubricate bearings upon assembly.
- Assemble bearing (53) to gear.
- Apply a small amount of grease to groove in gear, then assemble 11 balls (54) to groove.
- Assemble gear to sleeve (55), securing balls (54) in groove in gear.
- Assemble sleeve (55) and components to housing (50) – LEFT HAND THREADS.
- Assemble bearing (46) and lock nut (45) to body, securing with adapter (44) – LEFT HAND THREADS.
- Assemble bearing (48) to pinion (49).
- Assemble pinion (49) to housing (50).
- Assemble housing (50) to body (47) – LEFT HAND THREADS.
- Assemble coupling (42) to pinion and assemble "O" ring (43) to adapter (44). NOTE: "O" ring is to be free of oil and grease. Assemble angle section to tool, securing with lock nut (45) – LEFT HAND THREADS.

## GEARING DISASSEMBLY

- Remove angle section from tool.
- Remove ring gear (30 or 39) using a wrench on flats.
- Remove snap ring (34) and washer (33).
- Remove spindle(s) and gears from ring gear. NOTE: Keep gears grouped with mating spindle when disassembling double reduction gearing.
- Do not remove bearing (32) or spacer (31) unless damage is evident.
- To remove bearing (32) and spacer (31) from ring gear, press on spacer (31) from inside splined end of ring gear.
- Do not remove gear (38) from carrier assembly unless damage is evident. Gear (38) is press fit onto carrier assembly.

## GEARING ASSEMBLY

- Assemble spacer (31) and bearing (32) into ring gear, pressing on outer race of bearing.
- Coat shafts of spindle with ARO 33153 grease.
- Assemble gears to shafts of mating spindle.
- Lubricate sets of gears liberally with ARO 33153 grease (approximately 1/32 oz. per reduction).

- Assemble carrier assembly to spindle assembly for models with double reduction gearing.
- Assemble spindle(s) and gearing into ring gear. Rotate spindle and gears to align gear teeth with splines of ring gear.
- Assemble washer (33) to spindle, securing with snap ring (34).
- Thread ring gear (30 or 39) to tool, tightening with wrench on flats.
- Assemble angle housing section to tool.

## MOTOR DISASSEMBLY

- Remove angle housing section and gearing from tool.
- Remove spacer (25) and "O" ring (24).
- Tap front edge of housing to remove motor assembly. Locating pin (26) should also come out.
- Tap splined end of rotor (20) with a soft face hammer; motor will come apart. NOTE: Bearing (23) is light press fit on rotor.
- Remove end plate (18) and bearing (17) from rotor.

## MOTOR ASSEMBLY

- Lubricate bearing (17) with ARO 33153 grease.
- Assemble bearing (17) to end plate (18), pressing on outer race of bearing.
- Assemble end plate (18) to rotor, pressing on inner race of bearing.
- Coat five rotor blades (19) with ARO 29665 spindle oil and assemble to rotor slots – straight side out.
- Coat i.d. of cylinder (21) with ARO 29665 spindle oil and assemble over rotor. NOTE: Air inlet slots in end of cylinder must be aligned with two air inlet holes in end plate (18).
- Assemble bearing (23) to end plate (22), pressing on outer race of bearing.
- Assemble end plate (22) to rotor, pressing on inner race of bearing. Be sure rotor turns without binding.
- Insert locating pin (26) into .081" diameter blind hole at bottom of motor cavity in housing.
- Align notches of end plates and cylinder and install motor into housing, aligning notches with locating pin (26).
- Grease and assemble "O" ring (24) to end plate.
- Assemble spacer (25) to motor, with counterbore facing motor.
- Assemble gearing and angle housing section to tool.

## HOUSING DISASSEMBLY

- Clamp air inlet adapter (2) in a smooth face vise.
- Unthread housing (9) with a strap type wrench.
- Remove spacer (3), washer (4), exhaust cap (5), muffler pad (6), spring (7) and valve rod (8). CAUTION: Do not remove or adjust rubber portion of valve rod (8), as it is preset at the factory.
- Remove screen (1) from inlet adapter.
- Remove throttle pin (11) and spring (10).
- Models DA025B-( ) – Do not remove restrictor (14) unless damage is evident.

## HOUSING ASSEMBLY

- Lubricate throttle pin (11) with ARO 29665 spindle oil.
- Install spring (10) and throttle pin (11) into housing. NOTE: Align slot in throttle pin with air inlet holes in housing.
- Install valve rod assembly (8) into housing. NOTE: Throttle pin (11) should not pull out when valve rod (8) is seated properly.
- Install muffler pad (6) to exhaust cap.
- Install exhaust cap (5) to housing, aligning lever with throttle pin (11).
- Assemble spring (7), washer (4) and spacer (3) to tool, securing with inlet adapter (2).
- Clean and replace screen (1) in inlet adapter (2).
- Models DA025B-( ) – Grease and assemble "O" ring (15) to restrictor (14) and assemble to housing (9), with opening of restrictor positioned towards motor. Secure restrictor with retaining ring (16).

