

IMPULSE WRENCH

MODELS: PS227A-A5 AND PS267A-A5

NOTICE

Models PS227A-A5 and PS267A-A5 Impulse Wrenches are designed for assembly operations which require high speed rundown of fasteners with consistent torque delivery and reduced torque reaction.


ARO is not responsible for customer modification of tools for applications on which ARO was not consulted.

⚠ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.



PLACING TOOL IN SERVICE

- Always operate, inspect and maintain this tool in accordance with all regulations (local, state, federal and country), that may apply to hand held/hand operated pneumatic tools.
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 3/8" (10 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig (6.2 bar/620 kPa) maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.

USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.

- Always wear hearing protection when operating this tool.
- Keep hands, loose clothing and long hair away from rotating end of tool.
- Note the position of the reversing lever before operating the tool so as to be aware of the direction of rotation when operating the throttle.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not over-reach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool shaft may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by ARO.
- Use only impact sockets and accessories. Do not use hand (chrome) sockets or accessories.
- Impact wrenches are not torque wrenches. Connections requiring specific torque must be checked with a torque meter after fitting with an impact wrench.
- This tool is not designed for working in explosive atmospheres.

NOTICE

The use of other than genuine ARO replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest ARO Tool Products Authorized Servicer.

For parts and service information, contact your local ARO distributor, or the Customer Service Dept. of the Ingersoll-Rand Distribution Center, White House, TN at PH: (615) 672-0321, FAX: (615) 672-0601

ARO Tool Products

Ingersoll-Rand Company

1725 U.S. No. 1 North, PO Box 8000, Southern Pines, NC 28388-8000

©1997 INGERSOLL-RAND COMPANY PRINTED IN U.S.A








ARO

Part of worldwide Ingersoll-Rand

WARNING LABEL IDENTIFICATION

▲ WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.



ADJUSTMENTS

TORQUE ADJUSTMENT

To adjust the torque on these Twin Blade Impulse Wrenches, proceed as follows:

1. Remove the Adjustment Hole Plug.
2. Rotate the Drive Shaft until the Torque Adjustment Screw is visible in the opening.
3. Using a 1.5 mm hex wrench, rotate the Adjustment Screw clockwise to increase the torque output and counterclockwise to decrease the torque output. Do not rotate the Oil Plug.

NOTICE

Make all final adjustments at the job.


4. Replace the Adjustment Hole Plug.

CHANGING THE MECHANISM FLUID

To change the Mechanism Fluid in the Impulse Mechanism, proceed as follows:

1. Use a pointed probe to push the Spring Seat against the Retaining Sleeve Spring. While the Spring is compressed, use another pointed probe or thin blade screwdriver to remove the Retaining Ring. Lift the Spring Seat, Spring and Bit Retaining Sleeve off the Drive Shaft and remove the Bit Retaining Ball.
2. Remove the Rubber Housing Boot.

3. Using leather-covered or copper-covered vise jaws, carefully grasp the flats of the Mechanism Cover with the output end of the Drive Shaft downward.
4. Using an adjustable wrench, unscrew the the Motor Housing Assembly from the Mechanism Cover. This is a **left-hand thread**, rotate the Motor Housing **clockwise** to remove it. See Dwg. TPD1292.



(Dwg. TPD1292)


5. Lift the assembled motor off the Mechanism Cover and pull the mechanism assembly out of the Cover.
6. Using a 1.5 mm hex wrench, rotate the Torque adjustment Screw clockwise until the Screw stops. Rotate the Screw counterclockwise until it stops or makes six complete revolutions.
7. Using the special Tee Wrench furnished in the Tool Kit (Part No. 180PQ-99), remove the Oil Plug and Oil Plug Seal.

ADJUSTMENTS

8. With the oil plug opening downward over a container, rotate the Drive Shaft to purge the fluid from the mechanism.
9. Using the syringe and fluid from the Fluid Replacement Kit (Part No. EQ106S-K400), fill the mechanism with the fluid furnished in the Kit. See Dwg. TPD1265.

NOTICE

DO NOT SUBSTITUTE ANY OTHER FLUID. Failure to use the fluid provided could damage the tool, increase maintenance and decrease performance. Use only clean fluid in these tools.




(Dwg. TPD1265)

10. Submerge the fill opening in the remainder of the fluid, and using a wrench, rotate the Drive Shaft to purge any remaining air from the system.

11. Thread the Oil Plug with the Oil Plug Seal into the mechanism until it is snug.
12. Using a 1.5 mm hex wrench, turn the Torque Adjustment Screw clockwise until it stops. This is the maximum torque position.
13. Wipe the outside of the mechanism dry and clean and remove the Oil Chamber Plug. Using the syringe, withdraw 0.4 cc of fluid.
14. Install the Oil Chamber Plug and tighten it between 20 and 25 in-lb (2.3 and 2.8 Nm) torque.
15. Insert the mechanism assembly, output end leading, into the Mechanism Cover clamped in the vise jaws.
16. Insert the hex end of the rotor shaft into the hex recess at the rear of the Drive Shaft and thread the assembled Motor Housing onto the Mechanism Cover. This is a **left-hand thread**. Rotate the Housing **counterclockwise** to tighten it. See Dwg. TPD1294.

COUNTERCLOCKWISE TO TIGHTEN



(Dwg. TPD1294)

PLACING TOOL IN SERVICE

LUBRICATION



Ingersoll-Rand No. 50



Ingersoll-Rand No. 67




Ingersoll-Rand Fluid Part
No. EQ106S-400-1

Always use an air line lubricator with these tools. We recommend the following Filter-Lubricator-Regulator Unit:

USA - No. C22-04-G00

International - No. C16-C3-A29

After each 20 000 cycles, or as experience indicates, drain and refill the Impulse Unit Drive Assembly as instructed in this manual using the Fluid Replacement Kit (Part No. EQ106S-K400). Lubricate the hex drive and the output shaft before assembly.




(Dwg. TPD905-1)

HOW TO ORDER AN IMPULSE WRENCH

Model	Free Speed	Recommended Torque Range			
		Soft Draw		Hard Slam	
		ft-lb	Nm	ft-lb	Nm
PS227A-A5	9 000	6-11	8-15	12-22	16-30
PS267A-A5	8 000	7-14	10-19	13-26	18-35

MODELS PS227A-A5 AND PS267A-A5

5



MAINTENANCE SECTION

(Dwg. TPA1611)

PART NUMBER FOR ORDERING



PART NUMBER FOR ORDERING



	Motor Housing Assembly				Rear End Plate Assembly.....	180PQ-A12
	for model PS227A-A5	180SQ-A40		17	Rear End Plate	180PQ-12
	for model PS267A-A5	280SQ-A40	+	18	Rear Rotor Bearing	500A-22
1	Motor Housing			19	Cylinder Assembly	
	for model PS227A-A5	180SQ-40			for model PS227A-A5	180SQ-A3
	for model PS267A-A5	280SQ-40			for model PS267A-A5	280SQ-A3
2	Reverse Lever Assembly	180SQ-A328		20	Rear End Plate Alignment Pin.....	180SQ-152
3	Reverse Lever Seal	EQ106S-119		21	Front End Plate Alignment Pin	2400P-152
4	Reverse Lever Pin	EQ106S-152		22	Rotor	
5	Reverse Valve Assembly	180SQ-A329			for model PS227A-A5	180PQ-53
6	Reverse Valve Seal	EQ106P-283			for model PS267A-A5	280PQ-53
7	Throttle Lever	EQ106S-273	+	23	Vane Packet (set of 5 Vanes)	
8	Throttle Lever Pin	EQ106S-120			for model PS227A-A5	180PQ-42-5
9	Throttle Valve Spring	EQ106S-51			for model PS267A-A5	280PQ-42-5
10	Throttle Ball	180PQ-929			Front End Plate Assembly	180PQ-A11
11	Throttle Plunger	180SQ-298		24	Front End Plate	180PQ-11
12	Cylinder Alignment Pin	EQ106P-99		25	Alignment Pin	380SQ-298
13	Inlet Bushing	EQ106S-565	+	26	Front End Plate Bearing.....	500P-22
14	Exhaust Deflector Assembly	180PQ-A23		27	Front End Plate Spacer	180PQ-41
15	Deflector Retaining Pin	EQ106P-152				
16	Suspension Bail	EQ106S-365				
	Motor Assembly					
	for model PS227A-A5	180SQ-A53				
	for model PS267A-A5	280SQ-A53				

+ Indicates Motor Tune-up Kit part.

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

	Impulse Unit Drive Assembly		43	Blade Assembly (2)	
	for model PS227A-A5	180PQ-A200		for model PS227A-A5	180PQ-A267
	for model PS267A-A5	280PQ-A200		for model PS267A-A5	280PQ-A267
28	Housing Assembly		44	Blade Assembly Pin (2 per assembly)	500A-120
	for model PS227A-A5	180PQ-A31	◆ 45	Blade Spring (2)	180PQ-568
	for model PS267A-A5	280PQ-A31	46	Front Liner Cover Assembly	180PQ-A211
29	Torque Adjustment Screw	180PQ-230	47	Liner Cover Pin	180PQ-232
30	Adjustment Screw Plug Lock (2)	180PQ-283	48	Oil Plug	180PQ-277
31	Plug Lock Spring	180PQ-219	◆ 49	Oil Plug Seal	EQ110P-288
32	Plug Lock Screw	500A-230	50	Oil Stop Cap Assembly	180PQ-A38
◆ 33	Liner O-ring	180PQ-236	51	Stop Cap O-ring	EQ106P-288
34	Housing Cap	180PQ-207	◆ 52	Back-up Ring	380SQ-272
35	Rear Liner Cover Assembly	180PQ-A212	◆ 53	Front Liner Seal	EQ104S-236
◆ 36	Liner Cover O-ring	180PQ-240	◆ 54	Rear Liner Seal	180PQ-273
37	Liner Assembly		◆ 55	Drive Shaft Seal	180PQ-271
	for model PS227A-A5	180PQ-A203	◆ 56	Seal Back-up Ring	380PQ-272
	for model PS267A-A5	280PQ-A203		Mechanism Cover Assembly	
38	Liner Pin (4)	180PQ-298		for model PS227A-A5	180PQ-A727
39	Relief Valve		57	for model PS267A-A5	280PQ-A727
	for model PS227A-A5	180PQ-222		Mechanism Cover	
	for model PS267A-A5	280PQ-222		for model PS227A-A5	180PQ-727
40	Spring Guide Assembly			for model PS267A-A5	280PQ-727
	for model PS227A-A5	180PQ-A255	58	Cover Bushing	180PQ-641
	for model PS267A-A5	280PQ-A255	59	Bushing Spacer	180PQ-229
◆ 41	Spring Guide Seal	180PQ-272	60	Adjustment Hole Plug	180PQ-95
42	Drive Shaft		61	Warning Label	WARNING-2-99
	for model PS227A-A5	180PQ-626			
	for model PS267A-A5	280PQ-626B			

◆ Indicates Mechanism Tune-up Kit part.

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

62	Bit Chuck Assembly	180PQ-A667	*	Motor Tune-up Kit (includes illustrated items 18, 23 and 26)	
63	Bit Retaining Ball	EQ104S-929		for model PS227A-A5	180PQ-K500
64	Bit Retaining Sleeve	EQ104S-930		for model PS267A-A5	280PQ-K500
65	Retaining Sleeve Spring	EQ104S-931	*	Motor Tune-up Kit (includes illustrated items	
66	Spring Seat	EQ104S-932	*	items 33, 36, 41, 45, 49, 52, 53, 54, 55 and 56) . . .	180PQ-K600
67	Retaining Ring	EQ104S-933	*	Fluid Replacement Kit (includes Fluid Syringe,	
	Nameplate			Fill Tube and 4 oz. [31 mL] of Replacement Fluid)	EQ106S-K400
	for model PS227A-A5	PS227A-A5-301		Replacement Fluid (4 oz.)	EQ106S-400-1
	for model PS267A-A5	PS267A-A5-301		Tool Kit (includes all the specialized tooling	
68	Oil Daily Label	500P-69	*	required to repair these tools and consists of two	
69	Rubber Housing Boot			Spanner Plugs, a Tee Wrench with a special tip,	
	for model PS227A-A5	180SQ-2		and O-ring Installer Fixture and a pressing fixture	
	for model PS267A-A5	280SQ-2		has a Disassembly Arbor and Pressing Sleeve) . . .	180PQ-99
*	Drive Shaft Assembly (optional 3/8" Sq. Drive) . .	180P-A626			
	Socket Retaining Pin	5020-716			
	Retaining Pin Spring	401-718			

* Not illustrated.


MAINTENANCE SECTION

CHANGING THE MECHANISM FLUID

To change the Mechanism Fluid in the Impulse Mechanism, proceed as follows:

1. Use a pointed probe to push the Spring Seat (65) against the Retaining Sleeve Spring (64). While the Spring is compressed, use another pointed probe or thin blade screwdriver to remove the Retaining Ring (66). Lift the Spring Seat, Spring and Bit Retaining Sleeve (63) off the Drive Shaft (42) and remove the Bit Retaining Ball (62).
2. Remove the Rubber Housing Boot (69).
3. Using copper-covered vise jaws, carefully grasp the flats of the Mechanism Cover (57) with the output end of the Drive Shaft downward.
4. Using an adjustable wrench, unscrew the Motor Housing Assembly (1) from the Mechanism Cover. This is a **left-hand thread**, rotate the Motor Housing **clockwise** to remove it. Refer to Dwg. TPD1292.

CLOCKWISE TO LOOSEN




(Dwg. TPD1292)

5. Lift the assembled motor off the Mechanism Cover and pull the mechanism assembly out of the Cover.
6. Using a 1.5 mm hex wrench, rotate the Torque Adjustment Screw (29) clockwise until the Screw stops. Rotate the Screw counterclockwise until it stops or makes six complete revolutions.
7. Using the special Tee Wrench furnished in the Tool Kit (Part No. 180PQ-99), remove the Oil Plug (48) and Oil Plug Seal (49).
8. With the oil plug opening downward over a container, rotate the Drive Shaft to purge the fluid from the mechanism.
9. Using the syringe and fluid from the Fluid Replacement Kit (Part No. EQ106S-K400), fill the mechanism with the fluid furnished in the Kit. Refer to Dwg. TPD1293.

NOTICE


DO NOT SUBSTITUTE ANY OTHER FLUID.
Failure to use the fluid provided could damage the tool, increase maintenance and decrease performance. Use only clean fluid in these tools.



(Dwg. TPD1293)

10. Submerge the fill opening in the remainder of the fluid, and using a wrench, rotate the Drive Shaft to purge any remaining air from the system.
11. Thread the Oil Plug with the Oil Plug Seal into the mechanism until it is snug.
12. Using a 1.5 mm hex wrench, turn the Torque Adjustment Screw clockwise until it stops. This is the maximum torque position. Back the Screw off between 3/4 and 1-1/4 turns to avoid erratic readings.
13. Wipe the outside of the mechanism dry and clean and remove the Oil Chamber Plug. Using the syringe, withdraw .25 cc of fluid from PS227A-A5 models and .3 cc of fluid from PS267A-A5 models.
14. Install the Oil Chamber Plug and tighten it between 20 and 25 in-lb (2.3 and 2.8 Nm) torque.
15. Insert the mechanism assembly, output end leading, into the Mechanism Cover clamped in the vise jaws.
16. Insert the hex end of the rotor shaft into the hex recess at the rear of the Drive Shaft and thread the assembled Motor Housing onto the Mechanism Cover. This is a **left-hand thread**. Rotate the Housing **counterclockwise** to tighten it. Refer to Dwg. TPD1294.

COUNTERCLOCKWISE TO TIGHTEN



(Dwg. TPD1294)

MAINTENANCE SECTION


DISASSEMBLY

General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. When grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
3. Do not remove any part which is a press fit in or on an assembly unless the removal of that part is necessary for repairs or replacement.


Disassembly of the Impulse Mechanism

1. Use a pointed probe to push the Spring Seat (65) against the Retaining Sleeve Spring (64). While the Spring is compressed, use another pointed probe or thin blade screwdriver to remove the Retaining Ring (66). Lift the Spring Seat, Spring and Bit Retaining Sleeve (63) off the Drive Shaft (42) and remove the Bit Retaining Ball (62).
2. Remove the Rubber Housing Boot (69).
3. Using copper-covered vise jaws, carefully grasp the flats of the Mechanism Cover (57) with the output end of the Drive Shaft downward.
4. Using an adjustable wrench, unscrew the Motor Housing Assembly (1) from the Mechanism Cover. This is a **left-hand thread**, rotate the Motor Housing **clockwise** to remove it. (Refer to Dwg. TPD1292.)
5. Lift the assembled motor off the Mechanism Cover and pull the mechanism assembly out of the Cover. Remove the Bushing Spacer (59).
6. Using a 1.5 mm hex wrench, rotate the Torque Adjustment Screw (29) clockwise until the Screw stops. Rotate the Screw counterclockwise until it stops or makes six complete revolutions.
7. Using the special Tee Wrench furnished in the Tool Kit (Part No. 180PQ-99), remove the Oil Plug (48) and Oil Plug Seal (49).
8. With the oil plug opening downward over a container, rotate the Drive Shaft to purge the fluid from the mechanism.
9. Grasp the flats of the Housing Assembly (28) in vise jaws with the output end of the Drive Shaft downward.
10. Insert the pins of the spanner plug from the No. 180PQ-99 Tool Kit into the two holes in the Housing Cap (34). Using a wrench on the plug, unscrew and remove the Housing Cap from the Housing Assembly. Refer to Dwg. TPD1295.



(Dwg. TPD1295)

11. Stand the disassembly arbor from the Tool Kit, large end downward, on a workbench or the table of an arbor press. Insert the output end of the Drive Shaft into the central opening and either tap the Housing downward off the components or use the pressing sleeve in the Kit to press the Housing downward off the components. Refer to Dwg. TPD1296.




(Dwg. TPD1296)

12. Disassemble the components of the mechanism in the sequence shown in Drawing TPA1331 on Page 2.

Disassembly of the Motor


1. Grasp the Motor Housing (1) in vise jaws with the shaft of the Rotor (22) upward.
2. Insert the pins of the end plate spacer spanner into the holes in the Front End Plate Spacer (27). Using a wrench, unscrew and remove the Spacer. This is a **left-hand thread**; rotate the wrench **clockwise** to remove the Spacer. Refer to Dwg. TPD1297.



(Dwg. TPD1297)

MAINTENANCE SECTION

3. Reposition the Motor Housing in the vise jaws so that the vise jaws grip the end of the rotor shaft and the Housing is horizontal. Tap the edges of the Housing surrounding the motor bore with a plastic hammer to separate the Housing from the motor. Refer to Dwg. TPD1298.




(Dwg. TPD1298)

4. Remove the motor from the vise jaws and remove the Front End Plate (24), Front End Plate Bearing (26), Cylinder Assembly (19) and Vanes (23) from the Rotor.
5. On the table of an arbor press, support the Rear End Plate (25) with blocks as close to the Rotor as possible and press the Rotor out of the Rear End Plate and Rear Rotor Bearing (26).
6. To remove the Rear Rotor Bearing from the Rear End Plate, use a small drift or pin punch through the central opening of the Rear End Plate to tap the Bearing out of the End Plate. Refer to Dwg. TPD1299.

NOTICE

Do not enlarge or damage the shaft hole in the End Plate.



(Dwg. TPD1299)

7. Press the Reverse Lever Pin (4) out of the Reverse Lever (2) and remove the Reverse Lever, Reverse Lever Seal (3), Throttle Valve Spring (9) and the Throttle Ball (10).
8. Spread the end of the Suspension Bail (16), where the ends enter the Motor Housing, and remove the Bail.

9. Using a pin punch, tap the Throttle Lever Pin (8) and the Deflector Retaining Pin (15) out of the Handle. Remove the Throttle Lever (7), Throttle Plunger (11) and the Exhaust Deflector Assembly (14).
10. Push the Reverse Valve Assembly (5) out the throttle lever end of the Housing.
11. Unscrew and remove the Inlet Bushing (13).

ASSEMBLY

General Instructions

1. When grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
2. Always press on the inner ring of a ball-type bearing when installing the bearing on a shaft.
3. Always press on the outer ring of a ball-type bearing when pressing the bearing into a bearing recess.
4. Except for bearings and mechanism parts, always clean every part and wipe every part with a thin film of oil before installation.
5. Wipe a thin film of mechanism fluid on all internal mechanism components before installing them in the mechanism.
6. Apply a film of O-ring lubricant to every O-ring before installation.

Assembly of the Motor

1. Thread the Inlet Bushing (13) into the threaded hole at the rear of the handle of the Motor Housing (1) and tighten it between 30 and 35 ft-lb (40 and 47 Nm) torque.
2. Position the Exhaust Deflector Assembly (14) in the hole at the rear of the motor housing handle and install the Deflector Retaining Pin (15) to secure it in position.


NOTICE

It may be necessary to slide the Assembly in or out in order to align the groove in the Assembly with the pin hole.

3. Install the Reverse Valve Seal (6) in the groove next to the large hub of the Reverse Valve (5).
4. Install the Reverse Valve Assembly, seal end trailing, into the lever side of the Motor Housing. Make certain the square depression on the shaft of the Valve faces forward toward the output end of the tool.
5. Install the Reverse Lever Seal (3) in the groove on the small hub of the Reverse Lever (2).
6. Insert the Throttle Ball (10) followed by the Throttle Valve Spring (9) into the Reverse Valve Assembly.


MAINTENANCE SECTION

7. Position the Reverse Lever Assembly on the Reverse Valve Assembly with the indicator lever rearward. Make certain the crossholes in the Lever align with the pin holes in the Valve. Press the Reverse Lever Pin (4) into the Lever and Valve.
8. Insert the Throttle Plunger (11) into the Reverse Valve Assembly.
9. Position the Throttle Lever (7) on the Motor Housing and secure it by pressing the Throttle Lever Pin (8) into the Housing and Lever.
10. Using an arbor press and a piece of tubing that contacts the outer ring of the bearings, press the Front End Plate Bearing (26) into the Front End Plate (24) and the Rear End Plate Bearing (18) into the Rear End Plate (17). Refer to Dwg. TPD1300.




(Dwg. TPD1300)

11. Stand the Rotor (22) on the table of an arbor press. It should be upright on a flat metal plate having a clearance hole for the shaft. The shaft with the hex must be upward.
12. Place a 0.001" (0.025 mm) shim on the upward surface of the large portion of the rotor body. Using a piece of tubing that contacts the inner ring of the bearing, press the Front Rotor Bearing and Front End Plate, End Plate leading, onto the shaft of the Rotor until the End Plate contacts the shim. Remove the shim. Refer to Dwg. TPD1301.




(Dwg. TPD1301)

13. Coat each Vane (23) with a thin film of oil and insert a Vane into each of the rotor vane slots with the straight edge of the Vane outward.
14. Install the Cylinder (19) over the Vanes and Rotor with the end of the Cylinder having the Alignment Pin (21) in the middle of the four holes positioned toward the Front End Plate. Refer to Dwg. TPD1302. Make certain the Pin enters the hole in the face of the Front End Plate.



(Dwg. TPD1302)

15. Place the Rear End Plate and Bearing against the face of the Cylinder, Bearing end trailing. Make certain the Rear End Plate Alignment Pin (20) protrudes through the hole in the End Plate.
16. Insert the assembly, Rear End Plate leading, into the Motor Housing making sure the Alignment Pin protruding through the End Plate enters the proper hole in the Housing. It may be necessary to tap the assembly into position with a brass or plastic hammer. Refer to Dwg. TPD1303.




(Dwg. TPD1303)

17. Grasp the Motor Housing in vise jaws with the rotor shaft upward. Thread the Front End Plate Spacer (27) into the Housing and using the end plate spacer spanner, tighten the Spacer to 33 ft-lb (45 Nm) torque. This is a left-hand thread; rotate the wrench counterclockwise to tighten. Refer to Dwg. TPD1304.

MAINTENANCE SECTION

COUNTERCLOCKWISE TO TIGHTEN




(Dwg. TPD1304)

18. After installing the Front End Plate Spacer, grasp the shaft of the Rotor and rotate it by hand. If the Rotor does not turn easily, disassemble the motor unit and determine where the assembly is binding. The motor must rotate freely before proceeding further with the assembly.


Assembly of the Impulse Mechanism

1. Insert the long shaft with the annular groove of the Spring Guide (40) into the central opening of the O-ring Installer furnished with the Tool Kit (Part No. 180PQ-99). Place the Spring Guide Seal (41) on the tapered end of the installer and roll the Seal up the taper and into the groove on the large body of the Spring Guide. Refer to Dwg. TPD1305.




(Dwg. TPD1305)

2. Insert the Relief Valve (39), large end trailing, into the Liner (37). Insert the assembled Spring Guide, long hub with annular groove leading, into the Liner against the Relief Valve. Refer to Dwg. TPD1306.




(Dwg. TPD1306)

3. Place a Blade (43) into one of the slots of the Drive Shaft (42) with the Blade Assembly Pins (44) inward.
4. From the opposite side of the Shaft, encircle each Pin with a Blade Spring (45).
5. Install the Assembly Pins of the remaining Blade in the open ends of the Springs. Refer to Dwg. TPD1307.



(Dwg. TPD1307)


6. Compress the Springs with the Blades until both Blades are flush with the Drive Shaft and install the assembly in the Liner with the output end of the Drive Shaft protruding out the end of the Liner containing the Spring Guide. Refer to Dwg. TPD1308. Make certain the ends of the Blades are flush with the ends of the Liner.




(Dwg. TPD1308)

MAINTENANCE SECTION


7. Install the Drive Shaft Seal (55) followed by the Seal Back-up Ring (56) on the Drive Shaft against the hub. Refer to Dwg. TPD1309.




8. The Torque Adjustment Screw (29) can only be installed from the liner end of the Impulse Housing (28). If the Torque Adjustment Screw was removed, proceed as follows:
- Insert a 1.5 mm hex wrench into the threaded hole for the Torque Adjustment Screw from the oil plug end of the Housing.
 - From the opposite end of the Housing, install the hex of the Torque Adjustment Screw onto the hex wrench.
 - Push the Screw and wrench toward the threaded hole until it contacts the face of the Housing.
 - While applying finger pressure to the rivet end of the Screw, rotate the wrench counterclockwise to thread the Screw into the Housing. Continue rotating the Screw until the rivet end stops against the face of the Housing.
 - Insert the two Adjustment Screw Plug Locks (30) and the Plug Lock Spring (31) into the crosshole leading to the Adjustment Screw. Thread the Plug Lock Screw (32) into the same hole to capture the components. Refer to Dwg. TPD1310.



9. If the Oil Stop Cap Assembly (50) was removed from the Front Liner Cover (46), install the Stop Cap O-ring (51) and Back-up Ring (52) in the groove of the Cap and insert the assembly into the Cover. Refer to Dwg. TPD1311.




10. Install the Liner Cover O-ring (36) in the groove on the large hub of the Rear Liner Cover (35). Align the pin holes in the face of the Cover with the two Liner Pins (38) at the rear of the Liner and place the Cover against the Liner. A groove will be formed between the Liner and Cover for the Rear Liner Seal (54). Do not attempt to put the Seal in the groove at this time.
11. Align the pin holes in the Front Liner Cover (46) with the Pins in the front face of the Liner and place the Cover against the face of the Liner. Another groove will be formed between the Liner and Cover for the Front Liner Seal (53). Install both the Front and Rear Liner Seals in the grooves at this time and stand the assembly on the workbench with the output end of the Drive Shaft upward. Refer to Dwg. TPD1312.



12. Apply a thin film of grease to the Liner O-ring (33) and install it in the forward bore of the Housing.
13. Lubricate the Front and Rear Liner Seals and after orienting the Housing to the proper position, install the Housing over the Liner.


MAINTENANCE SECTION

14. Grasp the flats of the Housing in vise jaws with the output spindle downward. Remove the Rear Liner Cover Assembly and put grease in the central opening of the Cover. Refer to Dwg. TPD1313.




(Dwg. TPD1313)

15. Reinstall the Cover Assembly and use a hex wrench to push it below the threads at the rear of the Housing. Refer to Dwg. TPD1314.



(Dwg. TPD1314)

16. Install the Housing Cap (34) and using the spanner plug furnished in the Tool Kit, tighten the Cap between 58 and 65 ft-lb (78 and 88 Nm) torque. Refer to Dwg. TPD1315.



(Dwg. TPD1315)

17. Make certain the Drive Shaft rotates freely and then fill the mechanism with fluid and reassemble the tool as instructed in the section, **CHANGING THE MECHANISM FLUID.**

