

60806 SCREENED INLET KIT

CONVERSION KIT FOR USE ON ARO 2" DIAPHRAGM PUMPS

To Install Screen Conversion Kit:

1. Remove Four Lower (Inlet) Manifold Bolts.
2. Remove Manifold
3. Position 92871 Screen (Upper)
4. Replace Manifold.
5. Assemble remaining Kit Ass'y parts as shown.

NOTE: Material Inlet hole should be toward Cover Plate.

