

MOUNTING KIT INSTRUCTIONS

FOR PROVENAIR "HT" SERIES CYLINDERS

NOTICE

DO NOT re-use the screws removed from the cylinder.
This attachment requires use of the longer screws provided with this mounting kit for installation.
Use the proper minimum torque from the following table when installing the screws.

	Bore Size				
	1-1/2"	2"	2-1/2"	3-1/4"	4"
Torque (ft-lb)	9	16	21	35	49