

OPERATOR'S MANUAL

615154

INCLUDING: SERVICE KITS, GENERAL DESCRIPTION & TROUBLESHOOTING
ALSO INCLUDE MANUALS: 636077 "Z" Swivel, 636111 Control Handle


RELEASED:09-15-58
REVISED:08-16-93
IPP/PSE

Models 615154 and 615155 WALL TYPE SERVICE ASSEMBLY

**IMPORTANT: READ THIS MANUAL CAREFULLY BEFORE INSTALLING,
OPERATING OR SERVICING THIS EQUIPMENT.**

OPERATING INSTRUCTIONS

The 615154 wall type service assembly passes material at line pressure in a continuous flow. The control handle will continue to pass material as long as the lever is squeezed enough to lift the ball valve off the valve seat.



WARNING: HIGH PRESSURE DEVICE

- IMPROPER USAGE OF EQUIPMENT COULD RESULT IN SERIOUS INJURY. THE POSSIBILITY OF INJECTION INTO THE FLESH IS A POTENTIAL HAZARD. NEVER ALLOW ANY PART OF THE HUMAN BODY TO COME IN FRONT OF OR IN DIRECT CONTACT WITH THE MATERIAL OUTLET.
- AN INJECTION INJURY COULD BE SERIOUS! IF INJECTION SHOULD OCCUR, CONTACT A QUALIFIED PHYSICIAN FOR IMMEDIATE TREATMENT.
- DO NOT EXCEED MAXIMUM WORKING PRESSURE OF 7500 P.S.I. (517 BAR).

THE ARO CORPORATION • ONE ARO CENTER • BRYAN, OHIO 43506-0151
PH: (419) 636-4242 • FAX (419) 636-2115
©1993 THE ARO CORPORATION • PRINTED IN U.S.A.



PN 97999-280

Part of worldwide Ingersoll-Rand