
OPERATION, INSTALLATION, & MAINTENANCE

RELEASED: 8-20-81



(FOR SINGLE POST RAM 651605)



 Remove inlet connector from air regulator and install 1 street elbow. Reinstall inlet connector into 1.

NOTE: Make sure **1** elbow is installed to keep hose from interfering with **6** handle during lift operation.


- 2. Remove pump from cart and secure any loose accessories. Tip cart forward so that the underside of cart is exposed (See Fig. 1).
- 3. Locate 2 base stand as shown and secure with 3 Screw (2), 4 Lockwashers (2), 5 Nuts (2).

NOTICE: READ THIS MANUAL CAREFULLY BEFORE OPERATING, INSTALLING OR SERVICING THIS EQUIPMENT.

THE ARO CORPORATION

ONE ARO CENTER, BRYAN, OHIO 43506 PHONE - 419-636-4242





- 4. Locate handle on cart and allow installation of **7** retaining pin (as shown) and retain this assembly with **8** cotter pin.
- 5. Insert threaded end of **9** axle (2) thru **10** washer (2) and into base as shown. Secure with **11** nut (2).
- 6. Place **12** wheels (2) on **9** axle (2) and secure with **13** retaining ring (2).

PARTS LIST

REF. QTY. PART NO. DESCRIPTION

1	1	Y43-4-C	STREET ELBOW
2	1	90418-1	BASE STAND
3	2	Y8-58-C	SLOTTED ROUND HEAD SCREW 5/16" - 18
4	2	Y14-516-C	LOCK WASHER 5/16"
5	2	Y12-5-C	NUT 5/16'' - 18
6	1	75824	HANDLE
7	2	75834	RETAINING PIN
8	2	Y15-31-C	COTTER PIN 3/32" x 1/2"
9	2	98873	AXLE
10	2	Y14-625	LOCK WASHER 5/8"
11	2	Y11-10-C	NUT 5/8'' - 18
12	2	75823	WHEEL
13	2	90102	RETAINING RING