


INSTRUCTION SHEET 119338 GASKET KIT

FOR ALPHA "THIN" SERIES VALVE



Align the gasket on the bottom of the valve before installing onto the manifold.

NOTE: The open notch on the gasket will be toward the manifold rail.

THE ARO CORPORATION • ONE ARO CENTER • BRYAN, OHIO 43506-0151
PH: (419) 636-4242 • FAX (419) 636-2115

©1993 THE ARO CORPORATION • PRINTED IN U.S.A.



PN 119999-19 REV. 5-93

Part of worldwide Ingersoll-Rand