

Problem:


The screen is white or very light gray, but the system still runs.

Root Cause:

The LCD Connector has come loose or is installed incorrectly.



Solution:

Re-install the LCD Connector as shown below.



If installed correctly, there will be gaps on either side of the connector.

CAUTION: Installing this connector wrong can damage the Mother Board!



If installed wrong, the connector will be to one side and pins will be exposed.