


LA411-EU 3/8" Reversible Angle Drill - Exploded View



(Dwg. TPB926-1)

LA411–EU 3/8" Reversible Angle Drill - Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
1	Motor Housing	LA411–40	32	Front Rotor Bearing	LA411–34
2	Valve Bushing	LA411–93	33	Gear Case	LA411–37
3	Reverse Valve Bushing	LA411–330	34	Ring Gear	LA411–36
5	Inlet Bushing	LA411–565	35	Planet Gear (3)	LA411–10
6	Deflector	LA411–23	36	Gear Head	LA411–216
8	Deflector Stop Ring	LA411–28	37	Bearing Cage	LA411–70
9	Housing Cap	LA411–7	38	Spindle Shaft	LA411–41
10	Screw (2)	LA411–8	39	Spindle Bearing	LA411–66
11	Throttle Lever	LA411–273	40	Pinion	LA411–551
12	Throttle Lever Pin	LA411–120	41	Bevel Pinion Gear	LA411–552
13	Housing Gasket	LA411–739	42	Angle Housing	LA411–550
14	Valve Screw	LA411–60	43	Grease Fitting	LA411–879
15	Valve Screw O–ring	LA411–379	44	Spindle Upper Bearing	LA411–603
16	Throttle Valve Spring	LA411–51	45	Bevel Pinion Gear Retainer	LA411–531
17	Throttle Valve	LA411–302	46	Spindle	LA411–591
18	Throttle Valve O–ring	LA411–16	47	Bevel Pinion Gear Key	LA411–49
19	Reverse Retainer	LA411–20	48	Lower Spindle Bearing	LA411–593
21	Reverse Valve	LA411–329	49	Lower Spindle Bearing Cage	LA411–65
22	Reverse Valve Spring	LA411–515	50	Spindle Retainer	LA411–853
23	Rear Rotor Bearing	LA411–24	51	Angle Housing Set Screw	LA411–54
25	Motor Gasket	LA411–27	52	Chuck Screw	LA411–55
26	Rear End Plate	LA411–12	53	Upper Bearing Wave Washer	LA411–57
27	Cylinder	LA411–3	54	Drill Chuck (3/8")	LA411–99
28	Rotor	LA411–53	55	Nameplate	LA411–301
29	Vane (5)	LA411–42	56	Chuck Key	LA411–253
30	Cylinder Dowel	LA411–98	57	Warning Label	EU–99
31	Front End Plate	LA411–11			

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

Related Documentation

For additional information refer to:

Air Drill Product Safety Information Manual 04580353.

Air Drill Product Information Manual 16571846.

Manuals can be downloaded from www.ingersollrandproducts.com

