


43102SK Service Kit Exploded Diagram



(Dwg. 80156664)

43102SK Service Kit Parts List

Item	Part Number	Part Description	Quantity
1	37511	Screw	2
2	Y325-111	O-Ring	2
3	32858	Spring	2
4	34757	Valve	2
5	Y325-6	O-Ring	2
6	Y61-85-C	Screw	4
7	Y178-58	Roll Pin	2
8	45616-1	Down Lever	1
9	45616-2	Up Lever	1

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center. Refer all communications to the nearest **Ingersoll-Rand** Office or Distributor.

Manuals can be downloaded from www.irtools.com.



www.irtools.com

© 2005 Ingersoll-Rand Company

Form 80156730

Edition 1

March 2005