



Form 04584611
Edition 1
November 2004

Air Impact Wrench

205 and 206


Parts Information



Save These Instructions

IR Ingersoll-Rand®

205 and 206 Air Impact Wrench Exploded Diagram




(Dwg. TPB956)

205 and 206 Air Impact Wrench Parts List

Item	205	Item	206
1	205-A40	29	206-A40
2	205-302 (2)	30	223-93
3	205-55 (2)	31	223-524
4	205-A50 (2)	32	223-524
5	223-103 (2)	33	206-A94
6	205-106 (2)	34	223-314
7	205-51 (2)	35	223-50
8	205-125	36	223-223
9	222-69	37	223-A165
10	205-273	38	107-259
11	205-120 (2)	39	223-654
12	205-45	40	223-A302
13	205-36	41	223-103
14	205-354 (3)	42	223-118
15	205-358 (3)	43	223-51
16	205-A166	44	223-465
17	223-426	45	223-359 (2)
18	7802-291	46	223-58 (2)
19	205-175	47	206-A329
20	205-176	48	206-331 (2)
21	205-A165	49	206-421
22	223-426	50	206-422
23	205-255	51	206-299
24	205-250	52	206-739
25	205-168		
26	7802-262 (2)		
27	205-739 (2)		
28	205-740		

205 and 206 Air Impact Wrench Exploded Diagram



(Dwg. TPB957)

205 and 206 Air Impact Wrench Parts List

Item	205	206	Item	205	206
53	205-118	206-118	71	205-425	205-425
54	107-24	107-24	72	205-707	205-707
55	205-12	206-12	73	205-A727 (205)	206-A727 (206)
56	205-53	205-53	73	205-EU-A727 (205-EU)	206-EU-A727 (206-EU)
57	205-42-6 (set/6)	205-42-6 (set/6)	74	205-641	205-641
58	205-3	205-3	75	205-271	205-271
59	205-98	205-98	75A	222-99 (205)	222-99 (206)
60	205-A11	205-A11	75A	EU-99 (205-EU)	EU-99 (206-EU)
61	205-15	205-15	76	205-109	205-109
62	205-708	205-708	77	205-A377	205-A377
63	223-24	223-24	78	308-159	308-159
64	205-706	205-706	79	205-638 (4)	205-638 (4)
65	205-703	205-703	80	223-58 (4)	223-58 (4)
66	205-721	205-721	81	205-P32	---
67	205-724	205-724	82	205-301 (205)	206-301 (206)
68	205-704	205-704	82	205-EU-301 (205-EU)	206-EU-301 (206-EU)
69	205-A726 (3/8")	205-A726 (3/8")	83	222-302 (2)	222-203 (2)
70	205-426	205-426			

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center. Refer all communications to the nearest **Ingersoll-Rand** Office or Distributor.

Related Documentation

For additional information refer to:
Air Impact Wrench Product Safety Information Manual 04580916,
Air Impact Wrench Product Information Manual 04584868.

Manuals can be downloaded from www.irtools.com.



www.irtools.com

© 2004 Ingersoll-Rand Company