


E131 Series Air Impact Wrench - Exploded View



(Dwg. 46810751)

E131 Series Air Impact Wrench - Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
1	Housing Assembly	E131-A40	21	Rotor bearing	E131-22
2	Nameplate		22	Rear Endplate	E131-12
	For model E131	E131-301	23	Rotor bearing	E131-53
	For model LAE131	LAE131-301	24	Vane (6)	E131-42A
3	Warning Label	WARNING-27-99	25	Cylinder	E131-3
4	Trigger	E131-93	26	Front Endplate	E131-11
5	Pin	533-656	27	Dowel	230-98
6	Throttle Valve Seat	402-303	28	Bearing	E131-97
7	Throttle Valve Stem	402-302	29	Motor Clamp Washer(2)	227-207
8	O-Ring	405-159	30	Hammer Frame	E131-703
9	Throttle Valve	404-50-70A	31	Hammer(2)	231XP-724
10	Spring	R1A-51	32	Hammer Pin(2)	E131-704
11	Inlet Bushing Assembly	402-565	33	Anvil Assembly	E131-A626
12	Inlet Screen	--	34	O-Ring	R1A-159
13	Reverse Valve Gasket	PF800-282	35	Spring,Socket Retainer	2135-425
14	Reverse Valve Bushing	PF800-330	36	Hammer Case Assembly	E131-A727
15	Reverse Valve Assembly	236-A329	37	Bushing	705-941
16	O-Ring(2)	410-283	38	Hammer Case Gasket	E131-36
17	Spring	236-52	39	Pilot	405-800
18	Spring Cap	7811R-13	40	Hammer Case Lock Washer(3)	131-637
19	Retainer Pin	E131-120	41	Hammer Case Cap Screw(3)	131-638
20	Endplate Gasket	PF800-283	42	Rear Rotor Bearing Retainer	131-118

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

Related Documentation

For additional information refer to:

Air Impact Wrench Product Safety Information Manual 04580916.

Air Impact Wrench Product Information Manual 46809026.

Manuals can be downloaded from www.ingersollrandproducts.com