REVISED: (REV. 02)

67350 AND 67350-1 CYCLE COUNTER KITS

FOR DIAPHRAGM PUMPS

GENERAL DESCRIPTION

67350 kits include parts to adapt the Cycle Counter to the following ARO diaphragm pump models.

1"	1-1/2"	2"
PD10X-X	PD15X-X	PD20P-X
PE10X-X	PE15X-X	PE20P-X
PM10X-X-X-A02	PM15X-X-X-A02	
PW10X-X		

67350 INSTALLATION


NOTE: Refer to the pump Operator's Manual. **PEXXX-X models:**

1. Remove (Y17-50-S) pipe plug from the boss on the top of the valve

block. Continue with step 2, below.

PDXXX-X, PMXXX-X and PWXXX-X models:

- 1. a. Remove all valve components from the valve block (refer to pump Operator's Manual for disassembly procedure).
- 1. b. Drill and tap a 1/8 27 N.P.T. hole, centered on the boss on the top of the valve block. Thoroughly clean the valve block, as shavings from drilling / tapping may cause damage to valve components during pump operation.
- 1. c. Reassemble valve components to the valve block (refer to pump Operator's Manual for reassembly procedure).
- 2. Assemble (59756-4) elbow to threaded hole in top of valve block.
- 3. Remove two flange nuts from the fluid cap. Use the flange nuts to attach the (96284) bracket to the fluid cap (see figure 1).
- 4. Assemble the (59801) counter to the bracket, using the screws, lockwashers and nuts provided.
- Assemble the signal tubing to the counter input (marked "Z" on back of counter) and to (59756-4) elbow (cut tubing as necessary).



GENERAL DESCRIPTION


67350-1 kits include parts to adapt the Cycle Counter to the following ARO diaphragm pump models.

2"	3"
PD20R-X	PD30R-X-B
PD20Y-X	PM30R-X-X-B02
PF20R-X	
PF20Y-X	
PM20R-X-X-A02	

67350-1 INSTALLATION

NOTE: Refer to the pump Operator's Manual.

- Remove all valve components from the valve block (refer to pump Operator's Manual for disassembly procedure).
- Drill and tap a 1/8 27 N.P.T. hole, centered on the boss on the top of the valve block. Thoroughly clean the valve block, as shavings from drilling / tapping may cause damage to valve components during pump operation.
- 3. Reassemble valve components to the valve block (refer to pump Operator's Manual for reassembly procedure).
- Assemble (59474-4) connector to threaded hole in top of valve block.
- 5. Remove one screw from the top manifold. Use the screw to attach the (96262) bracket to the manifold (see figure 1).
- 6. Assemble the (59801) counter to the bracket, using the screw, lockwasher and nut provided.
- 7. Assemble the signal tubing to the counter input (marked "Z" on back of counter) and to (59474-4) connector (cut tubing as necessary).





PN 97999-1076

Page 2 of 2 67350-X